

## OPTISONIC 6300 Handbook

Ultrasonic clamp-on flowmeter



- 1 Safety instructions**
  - 1.1 Intended use..... 6
  - 1.2 Certification..... 6
  - 1.3 Safety instructions from the manufacturer ..... 6
    - 1.3.1 Disclaimer ..... 7
    - 1.3.2 Product liability and warranty..... 7
    - 1.3.3 Information concerning the documentation..... 7
    - 1.3.4 Display conventions ..... 8
  - 1.4 Safety instructions for the operator ..... 9
- 2 Instrument description**
  - 2.1 Scope of delivery ..... 10
  - 2.2 Instrument description ..... 11
  - 2.3 Nameplate..... 12
    - 2.3.1 OPTISONIC 6000..... 12
    - 2.3.2 UFC 300 Signal converter ..... 13
    - 2.3.3 Coding for I/O assemblies..... 14
- 3 Installation**
  - 3.1 Pre-installation requirements ..... 15
    - 3.1.1 Environmental requirements ..... 15
    - 3.1.2 Installation requirements ..... 15
  - 3.2 General installation notes..... 16
  - 3.3 Storage..... 16
  - 3.4 Transport ..... 16
  - 3.5 Installation requirements ..... 17
    - 3.5.1 Inlet, outlet and recommended mounting area ..... 17
    - 3.5.2 Long horizontal pipes..... 18
    - 3.5.3 Open feed or discharge..... 18
    - 3.5.4 Down going pipeline over 5 m /16 ft length..... 19
    - 3.5.5 Position of control valve..... 19
    - 3.5.6 Position of pump ..... 20
    - 3.5.7 Pipe diameters and transducer construction..... 20
    - 3.5.8 Pipe and media parameters ..... 20
  - 3.6 Installation ..... 20
    - 3.6.1 General installation notes..... 20
    - 3.6.2 Installation of rail with metal straps ..... 21
  - 3.7 Mounting of Converter ..... 22
    - 3.7.1 Mounting of UFC 300 F..... 22
    - 3.7.2 Mounting of UFC 300 W..... 22

## 4 Electrical connections

4.1	Safety instructions .....	23
4.2	Construction of the various housing versions .....	24
4.2.1	UFC 300 F .....	24
4.2.2	UFC 300 W .....	26
4.3	Electrical connection.....	26
4.3.1	OPTISONIC 6000, signal cable .....	27
4.3.2	UFC 300, power supply .....	28
4.3.3	UFC 300, signal cable.....	29
4.4	Basic inputs and outputs.....	30
4.4.1	General .....	31
4.4.2	Electrical symbol description .....	32
4.4.3	Current output (analog) .....	33
4.4.4	Pulse output (digital).....	33
4.4.5	Status output (digital).....	34
4.4.6	Control input (digital) .....	34
4.5	Connection via HART® .....	35
4.6	Modular Inputs and Outputs.....	37
4.6.1	Alterable I/Os .....	37
4.6.2	Current output active $I_a$ (HART®).....	38
4.6.3	Current output passive $I_p$ (HART®) .....	38
4.6.4	Pulse / frequency output active $P_a$ .....	39
4.6.5	Pulse / frequency output passive $P_p$ .....	39
4.6.6	Status output / limit switch active $S_a$ .....	40
4.6.7	Status output / limit switch passive $S_p$ .....	40
4.6.8	Control input active $C_a$ .....	41
4.6.9	Control input passive $C_p$ .....	41
4.6.10	Pulse, frequency and status output / limit switch passive $P_N / S_N$ to NAMUR EN 60947-5-6.....	42
4.6.11	Control input active $C_N$ to NAMUR EN 60947-5-6 .....	42
5	Start-up	
5.1	Start .....	43

**6 Operation**

6.1	Display and operating elements .....	44
6.2	Basic principles of operation .....	45
6.3	Menu overview .....	46
6.4	Menu structure.....	47
6.4.1	X Installation .....	47
6.4.2	Quick setup.....	49
6.4.3	Test.....	51
6.4.4	Setup .....	53
6.5	Installation menu .....	58
6.5.1	Installation menu X1...X6 .....	58
6.5.2	Pre programmed pipe and medium parameters .....	61
6.5.3	Installation menu X9.1...X9.3, install transducer .....	62
6.5.4	Set advised mounting distance.....	63
6.5.5	Installation menu X9.5...X9.7, check signal .....	65
6.5.6	Optimization loop, X9.8.1...X9.8.5.....	66
6.5.7	Set new advised mounting distance .....	67
6.5.8	Finish installation.....	68
6.5.9	Customize settings.....	69
6.6	Function description .....	70
6.7	Error messages.....	76

**7 Service**

7.1	Periodic maintenance .....	78
7.1.1	Greasing of transducers .....	78
7.2	Cleaning .....	79
7.3	Exchange of electronics unit .....	79
7.3.1	UFC 300 F .....	80
7.3.2	UFC 300 W .....	82
7.4	Replacing the main fuse.....	85
7.4.1	UFC 300 F .....	85
7.4.2	UFC 300 W .....	87
7.5	Spare parts availability .....	89
7.6	Service availability .....	89
7.7	Returning the device to the manufacturer .....	90
7.7.1	General information.....	90
7.7.2	Form (for copying) to accompany a returned instrument.....	91
7.8	Disposal.....	91

**8 Technical data**

8.1	Technical data .....	92
8.2	Dimensions and weights .....	95



# 1 SAFETY INSTRUCTIONS :

## 1.3.1 Disclaimer

KROHNE will not be liable for any damage of any kind by using its product, including, but not limited to direct, indirect, incidental, punitive and consequential damages.

This disclaimer does not apply in case KROHNE has acted on purpose or with gross negligence. In the event any applicable law does not allow such limitations on implied warranties or the exclusion of limitation of certain damages, you may, if such law applies to you, not be subject to some or all of the above disclaimer, exclusions or limitations.

Any product purchased from KROHNE is warranted in accordance with the relevant product documentation and our Terms and Conditions of Sale.

KROHNE reserves the right to alter the content of its documents, including this disclaimer in any way, at any time, for any reason, without prior notification, and will not be liable in any way for possible consequences of such changes.

## 1.3.2 Product liability and warranty

Ultrasonic flowmeters from KROHNE are designed solely for measuring the flow rate and the velocity of sound of process liquids.

Responsibility as to suitability and intended use of these ultrasonic flowmeters rests solely with the operator. The supplier does not accept any liability resulting from misuse by the operator. Improper installation and operation of the flowmeters (systems) may lead to loss of warranty. In addition, the “General conditions of sale” which forms the basis of the purchase agreement are applicable.

## 1.3.3 Information concerning the documentation

To prevent any injury to the user or flowmeter it is essential that you read the information in this document and observe applicable national standards, safety requirements and accident prevention regulations.

If this document is not in your native language and if you have any problems understanding the text, we advise you to contact your local KROHNE office for assistance. KROHNE can not accept responsibility for any damage or injury caused by misunderstanding of the information in this document.

This document is provided to help you establish operating conditions, which will permit safe and efficient use of this flowmeter. Special considerations and precautions are also described in the document, which appear in the form of underneath pictograms.









### 2.2 Instrument description

The OPTISONIC 6300 is an ultrasonic clamp-on flowmeter that can be fitted on the outside of piping to measure the flow rate of liquids.

The OPTISONIC 6300 is a combination of one up to three OPTISONIC 6000 Clamp-on sensor(s) and one UFC 300 ultrasonic flow converter.

**OPTISONIC 6000 + UFC 300 = OPTISONIC 6300**




Figure 2-2: System configuration possibilities

- 1 1 path; 1 pipe; wall housing
- 2 2 paths; 1 pipe; wall housing
- 3 2 paths; 2 pipes; wall housing
- 4 1 path; 1 pipe; field housing
- 5 2 paths; 1 pipe; field housing
- 6 2 paths; 2 pipes; field housing

For the OPTISONIC 6300 underneath accessories can be ordered optionally:

- GDC interface set (part number: XN0002100)
- SoundCheck (part number: 5316447200)
- Coupling grease; mineral (part number: X380030100)

### 2.3 Nameplate



#### NOTE!

Please check on the device nameplates, that the device is supplied according to your order. Check for the correct mains voltage printed on the nameplate. If not, contact your local KROHNE representative for advice.

#### 2.3.1 OPTISONIC 6000




Figure 2-3: Nameplate OPTISONIC 6000 - rail

- 1 Ambient temperature
- 2 Protection category
- 3 Calibration number
- 4 Process temperature
- 5 Manufacturing year
- 6 Serial number
- 7 Device type (yyy = small, medium or large)
- 8 Manufacturer

2.3.2 UFC 300 Signal converter




Figure 2-4: Nameplate UFC 300

- 1 Manufacturer
- 2 Device type
- 3 Manufacturing year
- 4 Serial number OPTISONIC 6000 sensor 1
- 5 Serial number OPTISONIC 6000 sensor 2
- 6 Empty

## 2 INSTRUMENT DESCRIPTION

### 2.3.3 Coding for I/O assemblies



<b>POWER</b>	<b>PE (FE)</b>	CG 34 xxxxxx    S/N: A06 xxxxx	<b>KROHNE</b>
	<b>L(L+)</b> <b>N(L-)</b>	  A = Active   P = Passive   NC = Not connected	
<b>INPUT / OUTPUT</b>	D - D	P	<b>PULSE OUT / STATUS OUT</b> $I_{max} = 100 \text{ mA} @ f \leq 10 \text{ Hz}; = 20 \text{ mA} @ f \leq 12 \text{ kHz}$ $V_o = 1.5 \text{ V} @ 10 \text{ mA}; U_{max} = 32 \text{ VDC}$
	C - C	P	<b>STATUS OUT</b> $I_{max} = 100 \text{ mA}; V_{max} = 32 \text{ VDC}$
	B - B	P	<b>STATUS OUT / CONTROL IN</b> $I_{max} = 100 \text{ mA}$ $V_{on} > 19 \text{ VDC}, V_{off} < 2.5 \text{ VDC}; V_{max} = 32 \text{ VDC}$
	A + A - A	A  P	<b>CURRENT OUT ( HART )</b> Active ( Terminals A & A+); $R_{Lmax} = 1 \text{ kohm}$ Passive ( Terminals A & A- ); $V_{max} = 32 \text{ VDC}$

Figure 2-5: Nameplate inputs / outputs



### 3 INSTALLATION

#### 3.2 General installation notes




Figure 3-1: Visual check

- 1 Rail
- 2 Signal converter

The following procedures have to be carried out before installing the flowmeter!

- Check the packing and the flowmeter itself for any damage.
- Check the contents of the consignment for completeness.
- Compare your order specification with the scope of delivery.
- Check nameplates at rail 1 and the signal converter 2

#### 3.3 Storage

- Store the flowmeter in a dry and dust-free location.
- Avoid lasting direct exposure to the sun.
- Store the flowmeter in its original packing.

#### 3.4 Transport

No special requirements.



### 3 INSTALLATION ::

#### 3.5 Installation requirements



**NOTE!**

To avoid measuring errors and malfunctioning of the flowmeter due to gas or air inclusions or an empty pipe, please observe the following precautions.



**CAUTION!**

Since gas will collect at the highest point of a pipe, installation of the flowmeter at that location should be avoided at all times. Also installation in a down going pipe should be avoided since a completely filled pipe may not be guaranteed due to cascading affects. Additionally flow profile distortion is possible.

##### 3.5.1 Inlet, outlet and recommended mounting area




Figure 3-2: Inlet, outlet and recommended mounting area

- 1 Min. 10 DN
- 2 Min. 5 DN
- 3 OK

### 3 INSTALLATION

#### 3.5.2 Long horizontal pipes

- Install on slightly ascending pipe section.
- If not possible, ensure adequate velocity to prevent air, gas or vapor from collecting in upper part.
- In partially filled pipes, the clamp-on flowmeter will report incorrect flow rates, or not measure.




Figure 3-3: Long horizontal pipes

#### 3.5.3 Open feed or discharge

Install meter on a lowered section of the pipe to ensure a full pipe condition through the meter.




Figure 3-4: Open feed or discharge

### 3 INSTALLATION ::

#### 3.5.4 Down going pipeline over 5 m /16 ft length

Install air vent downstream of the flow meter to prevent vacuum. Although this will not harm the meter, it may cause gases to come out of solution (cavitate) and interfere with proper measurements.




Figure 3-5: Down going pipeline over 5 m /16 ft length

#### 3.5.5 Position of control valve

Always install control valves downstream of flowmeter in order to avoid cavitation or distortion of flow profile.




Figure 3-6: Position of control valve

### 3 INSTALLATION

#### 3.5.6 Position of pump



**CAUTION!**

Never install flowmeter at a pump suction side in order to avoid cavitation or flashing in the flowmeter.




Figure 3-7: Position of pump

#### 3.5.7 Pipe diameters and transducer construction

Sensor type	Diameter range	Supported modes	Transducer construction
Small	DN15...100 / 0.5...4"	2 and 4 traverses (V and W mode)	transducer pair integrated in rail
Medium	DN50...400 / 2...16"	2 and 4 traverses (V and W mode)	transducer pair integrated in rail
Large	DN200...4000 / 8...160"	1 and 2 traverses (Z and V mode)	each transducer in separate rail

Table 3-1: Pipe diameters and transducer construction

#### 3.5.8 Pipe and media parameters



**NOTE!**

Detailed databases of most pipe and media parameters are on the supplied CD.

### 3.6 Installation

#### 3.6.1 General installation notes



**NOTE!**

No special tools for installing the mechanical part of this clamp-on flowmeter are required. An ordinary screw driver and Allen key are sufficient.

### 3 INSTALLATION ::

#### 3.6.2 Installation of rail with metal straps




Figure 3-8: Installation step 1...4

- | Clean pipe location and make sure that dust, grease, liquid and/or loose paint are removed
- | Take metal strap **1** and rail **2** from the package and click metal strap **1** into integrated rattle unit.
- | Position the rail with metal strap to the desired location in the correct flow direction.
- | Mount metal strap around pipe **3** and click end of the metal strap into the slide at the back side of the integrated rattle unit. **4**




Figure 3-9: Installation step 5...6

- | Pull metal strap moderately by hand. **5**
- | Secure rail to the pipe with screw using a screw driver. **6**









### Turning display of UFC 300 F

The display of the UFC 300 F can be turned in steps of 90°.




Figure 4-2: Turning display of UFC 300 F (field)

#### To do this,

- | Unscrew the cover of the electronics compartment 1 .
- | Pull the two metal clips to the left and right of the display 2 , using a screwdriver or similar tool.
- | The display between the metal clips can then be pulled off and re-inserted in the required position 3 and 4 .
- | Replace cover and tighten down by hand 5 .



#### CAUTION!

Before pushing back the clips simultaneously with the display into the electronics compartment, make sure not to kink the display's flat ribbon cable more than absolutely necessary.



#### NOTE!

Cover threads need to be protected from dirt and well greased at all times.

## 4 ELECTRICAL CONNECTIONS

### 4.2.2 UFC 300 W

The terminal compartments are accessible after opening cover **2**.




Figure 4-3: Construction of UFC 300 W (remote)

- 1 Cover, electronics compartment
- 2 Cover for the three separate terminal compartments for power, sensor connection and inputs/outputs
- 3 Locking screw, 1/2 turn left/right to open/close cover **2**
- 4 Sensor terminal compartment
- 5 Terminal compartment for inputs/outputs
- 6 Power terminal compartment, open separate shock-hazard protection cover

### 4.3 Electrical connection

- The UFC 300 signal converter is connected to the OPTISONIC 6000 transducer set via a single signal cable.
- Proper functioning is ensured when using this factory supplied signal cable.



#### INFORMATION!

The signal cable must be connected to the transducer terminal compartment of the UFC 300, taken into account the appropriate labelling.

## 4.3.1 OPTISONIC 6000, signal cable




Figure 4-4: Connect signal cable

To do this,

- | Take the signal cable with attached connector cap and connect the internal coax cable with identification “up” to the connector at the back of the rail with identification “up” . **1**
- | Repeat step above for the coax connection with identification “dn”.
- | Connect connector cap to the rail; secure the 2 socket screws using an Allen key size 4. **2**
- | Mount converter with mounting plate on wall; keep distance between transducer rail and converter as short as possible.
- | Connect signal cable to the converter according to wiring diagram.

## 4 ELECTRICAL CONNECTIONS

### 4.3.2 UFC 300, power supply



#### NOTE!

The power terminals in the terminal compartments equipped with additional hinged lids to prevent accidental contact.



#### DANGER!

Signal converter must be properly grounded to avoid personnel shock hazard. All directions, operating data and connection diagrams do not apply to devices used in hazardous areas.




Figure 4-5: UFC 300 F, power supply




Figure 4-6: UFC 300 W, power supply

#### 100...230 VAC (-15% / +10%)

- The protective ground conductor PE of the power supply is connected to the separate terminal in the terminal compartment of the signal converter.

#### 12...24 VAC/DC (24 VAC: +10% / -15%, 50/60 Hz; 24 VDC: +30% / -25%)

- For reasons to do with the measurement process, connect a functional ground FE to the separate U-clamp terminal in the terminal compartment of the signal converter.
- When connecting to functional extra-low voltages, provide a facility for protective separation (PELV) (VDE 0100 / VDE 0106 and/or IEC 364 / IEC 536 or relevant national regulations).

## 4 ELECTRICAL CONNECTIONS

### 4.3.3 UFC 300, signal cable



#### CAUTION!

Connect coax cables and follow indications up/down (1U 1D; 2U 2D; 3U 3D).




Figure 4-7: UFC 300 F, connect signal cable




Figure 4-8: UFC 300 W, connect signal cable

## 4 ELECTRICAL CONNECTIONS

### 4.4 Basic inputs and outputs

The OPTISONIC 6300 has several in / output ports, accessible via the terminal compartment of the UFC 300 signal converter for interfacing with external devices. The terminal compartment is accessible after unscrewing cover.




Figure 4-9: UFC 300 F, I/O terminals




Figure 4-10: UFC 300 W, I/O terminals

The input / output groups are galvanic separated from each other and from all other input and output circuits.

- **Active I/O:** the UFC 300 signal converter supplies the power for operation
- **Passive I/O:** an external power supply is required



## 4 ELECTRICAL CONNECTIONS . . . . .

### 4.4.2 Electrical symbol description







 <p style="text-align: center;">mA</p>	mA meter
 <p style="text-align: center;">U<sub>ext</sub></p>	External voltage source
	Current voltage source, in-house
	Steered current generator, in-house
	Electronic totalizer
	Push-button

Table 4-1: Symbol description



## 4 ELECTRICAL CONNECTIONS

### 4.4.3 Current output (analog)




Figure 4-11: Connection current output

- 1 **Active mode:** load impedance  $R_l \leq 1 \text{ k}\Omega$  at  $I \leq 22 \text{ mA}$
- 2 **Passive mode:** external power supply;  $U_{\text{ext}} \leq 32 \text{ VDC}$  at  $I \leq 22 \text{ mA}$

### 4.4.4 Pulse output (digital)




Figure 4-12: Connection pulse output passive ( $P_p$ )

- 1  $R = 1.2 \text{ k}\Omega / 0.5 \text{ W}$ , only necessary when using 2
- 2 Electronic totalizer with internal resistance of more than  $5 \text{ k}\Omega$

- **Passive mode:**  
external power supply;  $U_{\text{ext}} \leq 32 \text{ VDC}$  at  $I \leq 20 \text{ mA}$  and  $\text{freq} \leq 10 \text{ kHz}$
- **Active mode:**  
internal power supply;  $U_{\text{nom}} \leq 24 \text{ VDC}$  at  $I \leq 20 \text{ mA}$  and  $\text{freq} \leq 10 \text{ kHz}$
- **NAMUR mode:**  
passive in accordance with EN 60947-5-6

## 4 ELECTRICAL CONNECTIONS

### 4.4.5 Status output (digital)




Figure 4-13: Connection status output passive ( $S_p$ ); (X = terminals B or D)

- **Passive mode:**  
external power supply;  $U_{ext} \leq 32$  VDC at  $I \leq 100$  mA and  $freq \leq 10$  kHz
- **Active mode:**  
internal power supply;  $U_{nom} \leq 24$  VDC at  $I \leq 100$  mA and  $freq \leq 10$  kHz
- **NAMUR mode:**  
passive in accordance with EN 60947-5-6

### 4.4.6 Control input (digital)




Figure 4-14: Connection control input passive ( $C_p$ )

1 Signal

- $U_{ext} \leq 32$  V DC
- $I_o$  16 mA at 24 V
- $I \leq 20$  mA
- $U_{on} > 19$  VDC
- $U_{off} < 2.5$  VDC

### 4.5 Connection via HART®



**NOTE!**

In the Basic I/O, the current output at terminals A+ / A- / A is always HART®-compatible!

In the Modular I/O, only the current output module for terminals C / C- is HART®-compatible!




Figure 4-15: HART® connection active (I<sub>a</sub>)

- 1 Basic I/O terminal A and A+
- 2 Modular I/O terminal C and C-
- 3 HART® communicator




Figure 4-16: HART® connection passive ( $I_p$ )

- 1 Basic I/O terminal A and A-
- 2 Modular I/O terminal C and C-
- 3 HART® communicator

- $I$ :  $I_{0\%} = 4 \text{ mA}$
- **Multidrop I:**  $I_{\text{fix}} = 4 \text{ mA}$
- $U_{\text{ext}} \leq 32 \text{ VDC}$ :  $R \geq 230 \ \Omega$

## 4.6 Modular Inputs and Outputs



### INFORMATION!

In the following connection diagrams, the terminals A, B, C or D (depending on the version of the UFC 300) are marked with a "X".

### 4.6.1 Alterable I/Os

CG-No.	Terminals								
	D-	D	C-	C	B-	B	A-	A	A+
4	P <sub>a</sub> / S <sub>a</sub> <sup>1</sup>		I <sub>a</sub> + HART® active		max. 2 option modules for terminals <b>B + A:</b> I <sub>a</sub> or P <sub>a</sub> / S <sub>a</sub> or C <sub>a</sub>				
8	P <sub>a</sub> / S <sub>a</sub> <sup>1</sup>		I <sub>p</sub> + HART® passive		max. 2 option modules for terminals <b>B + A:</b> I <sub>p</sub> or P <sub>a</sub> / S <sub>a</sub> or C <sub>a</sub>				
6	P <sub>p</sub> / S <sub>p</sub> <sup>1</sup>		I <sub>a</sub> + HART® active		max. 2 option modules for terminals <b>B + A:</b> I <sub>a</sub> or P <sub>p</sub> / S <sub>p</sub> or C <sub>p</sub>				
B	P <sub>p</sub> / S <sub>p</sub> <sup>1</sup>		I <sub>p</sub> + HART® passive		max. 2 option modules for terminals <b>B + A:</b> I <sub>p</sub> or P <sub>p</sub> / S <sub>p</sub> or C <sub>p</sub>				
7	P <sub>N</sub> / S <sub>N</sub> NAMUR <sup>1</sup>		I <sub>a</sub> + HART® active		max. 2 option modules for terminals <b>B + A:</b> I <sub>a</sub> or P <sub>N</sub> / S <sub>N</sub> or C <sub>N</sub>				
C	P <sub>N</sub> / S <sub>N</sub> NAMUR <sup>1</sup>		I <sub>p</sub> + HART® passive		max. 2 option modules for terminals <b>B + A:</b> I <sub>p</sub> or P <sub>N</sub> / S <sub>N</sub> or C <sub>N</sub>				

<sup>1</sup> changeable

### Option modules

Abbreviation	Description	Ident. for CG No.
I <sub>a</sub>	Active current output	A
I <sub>p</sub>	Passive current output	B
P <sub>a</sub> / S <sub>a</sub>	Active pulse, frequency, status output or limit switch	C
P <sub>p</sub> / S <sub>p</sub>	Passive pulse, frequency, status output or limit switch	E
P <sub>N</sub> / S <sub>N</sub>	Pulse, frequency, status output or limit switch to NAMUR	F
C <sub>a</sub>	Active control input	G
C <sub>p</sub>	Passive control input	K
C <sub>N</sub>	Control input to NAMUR	H
-	No module installed	8
-	No further module possible	0

## 4 ELECTRICAL CONNECTIONS ::::::::::::::::::::::::::::::::::

### 4.6.2 Current output active $I_a$ (HART<sup>®</sup>)




Figure 4-17: Current output active  $I_a$

- $U_{int} = 24 \text{ VDC}$
- $I \leq 22 \text{ mA}$
- $R_L \leq 1 \text{ k}\Omega$

### 4.6.3 Current output passive $I_p$ (HART<sup>®</sup>)




Figure 4-18: Current output passive  $I_p$

- $I \leq 22 \text{ mA}$
- $U_{ext} \leq 32 \text{ VDC}$



## 4 ELECTRICAL CONNECTIONS ::::::::::::::::::::::::::::::::::

### 4.6.6 Status output / limit switch active $S_a$




Figure 4-21: Status output / limit switch active  $S_a$

- $U_0 = 1.5 \text{ V}$  at 10 mA
- $I \leq 100 \text{ mA}$
- $U_{\text{nom}} = 24 \text{ VDC}$

### 4.6.7 Status output / limit switch passive $S_p$




Figure 4-22: Status output / limit switch passive  $S_p$

- $U_0 = 1.5 \text{ V}$  at 10 mA
- $U_{\text{ext}} = 32 \text{ VDC}$
- $I \leq 100 \text{ mA}$



## 4 ELECTRICAL CONNECTIONS

### 4.6.8 Control input active $C_a$




Figure 4-23: Control input active  $C_a$

1 Signal

- $I_{nom} = 16 \text{ mA}$
- $U_{nom} = 24 \text{ VDC}$

### 4.6.9 Control input passive $C_p$




Figure 4-24: Control input passive  $C_p$

1 Signal

- $U_{on} > 19 \text{ VDC}$
- $U_{off} < 2.5 \text{ VDC}$
- $U_{ext} \leq 32 \text{ VDC}$
- $U_{nom} = 16 \text{ mA}$













## 6 OPERATION

### X6 pipe data 1

(underneath X6 until X8 become active if <b>two pipes</b> are selected in X4)					
X6	pipe data 1		>		↑↓
	X6.2	pipe tag	>	fill in 12 pos using ↑↓>	^
	X6.3	diameter	>	fill in using ↑↓>	^
	X6.4	pipe material	>	select from list using ↑↓>	^
	X6.5	VoS pipe material	>	read advise and/or fill in using ↑↓>	^
	X6.6	wall thickness	>	fill in using ↑↓>	^
	X6.7	liner material	>	select from list using ↑↓>	^
	X6.8	VoS liner material	>	read advise and/or fill in using ↑↓>	^
	X6.9	liner thickness	>	fill in using ↑↓>	^
	X6.10	fluid	>	select from list using ↑↓>	^
	X6.11	VoS fluid	>	read advise and/or fill in using ↑↓>	^
	X6.12	density	>	read advise and/or fill in using ↑↓>	^
	X6.13	viscosity	>	fill in using ↑↓>	^

### X7 pipe data 2

X7	pipe data 2		>		↑↓
	X7.1	copy pipe 1 data	>	start to copy ?	↑↓
				<b>if no:</b>	copy pipe 1 data appears Go to X7 Fill in menu X7.2 up to X7.13: is similar to X6.2 up to X6.13
				<b>if yes:</b>	copy pipe 1 data appears after copy process
<b>(end)</b>					

### X9 install transd. 1

X9	install transd. 1		>	X9.1, X9.2,...	↑↓
	X9.1	transducer set	>	read preset Ta,Tb,Tc / confirm or overrule using ↑↓>	
	X9.2	calibration number		read	^
	X9.3	number of traverses	>	read preset 1,2,4 / confirm or overrule using ↑↓>	
	X9.4	mount transducers at		read advise	^
please wait: decoupling 30 seconds					
	X9.5	act. flow, preliminary		read	^
	X9.6	check signal		read (0 - 100 %)	^
	X9.7	actual distance	>	fill in using ↑↓>	^
	X9.9	act. flow, preliminary		<b>(press key to continue)</b>	^
	X9.10	path ready ?	>	yes/no	↑↓
				<b>if no:</b>	go to X9
				<b>if yes and one pipe</b> , one path is selected in X4:	continue with X9.11
				<b>if yes and two pipes</b> are selected in X4:	continue with X10
				<b>if yes and two paths</b> are selected in X5:	continue with X9
	X9.11	end installation	>	yes/no	↑↓
				<b>if no:</b>	go to X9
				<b>if yes:</b>	display switches to measuring screen



### X10 install transd. 2

(underneath X10 becomes active if <b>two pipes or two paths</b> are selected in X4)					
X10	install transd. 2	>		↑↓	
			submenus identical to X9.1 up to X9.10		
			if no:	go to X10	
			if <b>yes and two pipes</b> are configurated:	continue with X9.11	
			if <b>yes and two paths</b> are configurated:	continue with X9.11	
					^
(end)					

### X12 transducer sets

X12	transducer sets	>	X12.1, X12.2,...	↑↓	
	X12.1	Ta serial no.	>	fill in using ↑↓>	^
	X12.2	Ta calibration no.	>	fill in using ↑↓>	^
	X12.3	Tb serial no.	>	fill in using ↑↓>	^
	X12.4	Tb calibration no.	>	fill in using ↑↓>	^
	X12.5	Tc serial no.	>	fill in using ↑↓>	^
	X12.6	Tc calibration no.	>	fill in using ↑↓>	^

## 6.4.2 Quick setup

### A1 language

A1	language	>	english / german / french	↑↓	^
----	----------	---	---------------------------	----	---

### A2 Tag

A2	Tag	>	fill in using ↑↓>		^
----	-----	---	-------------------	--	---

### A3 reset

A3	reset	>	A3.1, A3.2,...	↑↓	
	A3.1	reset errors		yes/no	↑↓
	A3.2	counter 1		yes/no	↑↓
	A3.3	counter 2		yes/no	↑↓
(underneath counter becomes active if modular IO)					
	A3.4	counter 3		yes/no	↑↓
(end)					

### A4 analogue outputs

A4	analog outputs	>	A4.1, A4.2,...	↑↓	
	A4.1	measurement	>	select from list using ↑↓>	^
				use at all outputs	↑↓
				yes/no	^
			if no:	only HART current output is selected	
			if yes:	all analog outputs are selected	
	A4.2	unit	>	select from list using ↑↓>	^
	A4.3	range	>	fill in using ↑↓>	^
				use at all outputs	↑↓
				yes/no	^



6.4.3 Test

B1 simulation

B1	simulation		>	B1.1, B1.2,...	↑↓	
	B1.1	volume flow	>	set value/cancel	↑↓	
				start simulation	↑↓	
				yes/no		^
<i>(underneath B1.1 until B1.3 become active if two pipes or two paths are selected in X4 and X5)</i>						
	B1.1	volume flow 1	>	set value/cancel	↑↓	
				start simulation	↑↓	
				yes/no		^
	B1.2	volume flow 2	>	submenu identical to B1.1	↑↓	
<i>(end)</i>						
	B1.4	vel. of sound	>	set value/cancel	↑↓	
				start simulation	↑↓	
				yes/no		^
<i>(underneath B1.4 until B1.5 become active if two pipes or two paths are selected in X4 and X5)</i>						
	B1.4	vel. of sound 1	>		↑↓	
				set value/cancel		
				start simulation	↑↓	
				yes/no		^
	B1.5	vel. of sound 2	>	submenu identical to B1.4	↑↓	
<i>(end)</i>						
	B1.7	terminal A <i>(depends on IO setting hardware)</i>	>	select from list using ↑ ↓ >		^
	B1.8	terminal B <i>(depends on IO setting hardware)</i>	>	select from list using ↑ ↓ >		^
	B1.9	terminal C <i>(depends on IO setting hardware)</i>	>	select from list using ↑ ↓ >		^
	B1.10	terminal D <i>(depends on IO setting hardware)</i>	>	select from list using ↑ ↓ >		^



## 6.4.4 Setup

### C setup

C	setup	>		↑↓	
---	-------	---	--	----	--

### C1 process input 1

(underneath C1 becomes active if <b>two pipes</b> are selected in X4)						
C1	process input 1		>	C1.1, C1.3,...	↑↓	^
	C1.1	number of pipes	>	read		^
	C1.3	pipe data	>	C1.3.1	↑↓	
	C1.3.1	pipe tag				
(further submenus C1.3.2 up to C1.3.12 are identical to X6.2 up to X6.13)						
	C1.4	transducer data	>	C1.4.1,...	↑↓	^
	C1.4.1	transducer set	>	Ta,Tb,Tc,none	↑↓	^
	C1.4.2	number of traverses	>	1,2,4	↑↓	^
	C1.4.3	actual distance	>	fill in using ↑↓>		^
	C1.5	extra measurements	>	select on pipe 1, on pipe 2		^
	C1.6	calibration	>	C1.6.1, C1.6.2,...	↑↓	
	C1.6.1	zero calibration	>	calibrate zero ?	select cancel, automatic, default	
	C1.6.2	meter factor	>	fill in using ↑↓>		^
	C1.6.3	Reynolds correction	>	on,off	↑↓	^
	C1.7	filter	>	C1.7.1, C1.7.2,...	↑↓	^
	C1.7.1	limitation	>	fill in using ↑↓>		^
	C1.7.2	flow direction	>	normal/reverse	↑↓	^
	C1.7.3	time constant	>	fill in using ↑↓>		^
	C1.7.4	low flow cutoff	>	fill in using ↑↓>		^
	C1.8	simulation	>	C1.8.1, C1.8.2,...	↑↓	^
	C1.8.1	volume flow	>	set value/cancel	↑↓	
				start simulation	↑↓	
				yes/no		^
	C1.8.2	vel. of sound	>		↑↓	
				set value/cancel	↑↓	
				start simulation	↑↓	
				yes/no		^
	C1.9	plausibility	>	C1.9.1, C1.9.2,...	↑↓	^
	C1.9.1	error limit	>	fill in using ↑↓>		^
	C1.9.2	counter decrease	>	fill in using ↑↓>		^
	C1.9.3	counter limit	>	fill in using ↑↓>		^
	C1.10	information	>	C1.10.1, C1.10.2,...	↑↓	^
	C1.10.1	sensor CPU		read		
	C1.10.2	sensor DSP		read		^
	C1.10.3	sensor driver		read		^

### C2 process input 2

C2	process input 2		>		↑↓	
(further submenus C2.1 up to C2.10 are identical to C1.2 up to C1.1)						
(end)						

## C1 process input

(underneath C1 becomes active if <b>two paths</b> are selected in X5)					
C1	process input	>	C1.1, C1.2,...	↑↓	
	C1.1	number of pipes	> read		^
	C1.2	pipe 1: total paths	> read		^
	C1.3	pipe data	> C1.3.1, C1.3.2,...	↑↓	^
	C1.3.1	pipe tag			
(further submenus C1.3.2 up to C1.3.12 are identical to X6.2 up to X6.13)					
	C1.4	transducer data	> C1.4.1, C1.4.2,...	↑↓	
	C1.4.1	transducer set 1	> Ta,Tb,Tc,none	↑↓	^
	C1.4.2	number of traverses 1	> 1,2,4	↑↓	^
	C1.4.3	actual distance 1	> fill in using ↑ ↓ >	↑↓	
	C1.4.4	transducer set 2	> Ta,Tb,Tc,none	↑↓	^
	C1.4.5	number of traverses 2	> 1,2,4	↑↓	^
	C1.4.6	actual distance 2	> fill in using ↑ ↓ >	↑↓	
	C1.6	calibration	> C1.6.1, C1.6.2,...	↑↓	^
	C1.6.1	zero calibration	> calibrate zero ?	select cancel, automatic, default	
	C1.6.2	meter factor	> fill in using ↑ ↓ >		^
	C1.6.3	Reynolds correction	> on,off	↑↓	^
	C1.7	filter	> C1.7.1, C1.7.2,...	↑↓	^
	C1.7.1	limitation	> fill in using ↑ ↓ >		^
	C1.7.2	flow direction	> normal/reverse	↑↓	^
	C1.7.3	time constant	> fill in using ↑ ↓ >		^
	C1.7.4	low flow cutoff	> fill in using ↑ ↓ >		^
	C1.8	simulation	> C1.8.1, C1.8.2,...	↑↓	^
	C1.8.1	volume flow	> set value/cancel	↑↓	
			start simulation	↑↓	
			yes/no		
	C1.8.2	vel. of sound	> set value/cancel	↑↓	
			start simulation	↑↓	
			yes/no		
	C1.9	plausibility	> C1.9.1, C1.9.2,...	↑↓	^
	C1.9.1	error limit	> fill in using ↑ ↓ >		^
	C1.9.2	counter decrease	> fill in using ↑ ↓ >		^
	C1.9.3	counter limit	> fill in using ↑ ↓ >		^
	C1.10	information	> C1.10.1, C1.10.2,...	↑↓	^
	C1.10.1	sensor CPU	read		^
	C1.10.2	sensor DSP	read		^
	C1.10.3	sensor driver	read		^

## C4 transducer sets

C4	transducer sets	>	C4.1, C4.2,...	↑↓	^
	C4.1	Ta serial no.	> fill in using ↑ ↓ >		^
	C4.2	Ta calibration no.	> fill in using ↑ ↓ >		^
	C4.3	Tb serial no.	> fill in using ↑ ↓ >		^
	C4.4	Tb calibration no.	> fill in using ↑ ↓ >		^
	C4.5	Tc serial no.	> fill in using ↑ ↓ >		^
	C4.6	Tc calibration no.	> fill in using ↑ ↓ >		^

















## 6 OPERATION

Pipe material	VoS		Density	
	[m/s]	[ft/s]	[kg/m <sup>3</sup> ]	[lbs/ft <sup>3</sup> ]
Refrigerant	800	2667	1.5	0.09
Caustic soda	2040	6800	1.25	0.08
solvents	1200	4000	0.8	0.05
other	1500	5000	1.0	0.06

Table 6-5: Velocity of sound and density of fluids

### 6.5.3 Installation menu X9.1...X9.3, install transducer

- I X9.1: Read factory preset transducer code (Ta/Tb/Tc) from rail.
- X9.2: Carefully check factory preset calibration number.
- X9.3: Read factory preset number of traverses.




Figure 6-2: Installation transducer

- 1 Z mode; 1 traverse: for large diameter pipes
- 2 V mode; 2 traverses: for small and medium diameter pipes
- 3 W mode; 4 traverses: for small and medium diameter pipes

#### X9 install transd. 1

X9	install transd. 1	>	X9.1, X9.2,...	↑↓	
	X9.1	transducer set	>	read preset Ta,Tb,Tc / confirm or overrule using ↑↓>	
	X9.2	calibration number		read	^
	X9.3	number of traverses	>	read preset 1,2,4 / confirm or overrule using ↑↓>	
	X9.4	mount transducers at		read advise	^
please wait: decoupling 30 seconds					

### 6.5.4 Set advised mounting distance

- | X9.4: Read the advised mounting distance.




Figure 6-3: Set advised mounting distance

- 1 Floating transducer
- 2 Locking knob
- 3 Reading point

### Set advised mounting distance by doing the following steps:

- | Release rail via the push buttons.
- | Unlock floating transducer 1 by turning locking knob 2 counter clockwise.
- | Slide transducer 1 via locking knob 2 to the advised mounting distance (reading in menu X9.4).
- | Lift rail, turn rail and grease transducer surfaces (see following figure for procedure and for detailed information please also refer to Greasing of transducers on page 78).
- | Turn locking knob 2 clockwise until tightenend.
- | Press rail at both ends to the pipe by clicking.




Figure 6-4: Grease transducer surfaces



**NOTE!**

OPTISONIC 6300 is mounted to the pipe and ready for first preliminary measurement. In the display appears "please wait". After 5...30 seconds the signal is stabilized and the message will disappear.

























## 6 OPERATION

Menu No.	Display	Function description	Selection list
C8.3		settings for first and second measurement display	
C8.3.1	function		one, two, three line(s)
C8.3.2	measurement 1.line		(depends on pipe configuration: 1 or 2 pipes) volume flow, mass flow, VoS, flow speed, gain, SNR, diagnosis value, volume flow 1 or 2, VoS 1 or 2
C8.3.3	range	set measurement range from 0 to 100 %	(depends on parameter settings)
C8.3.4	limitation	set lower and upper limit	min-max: -150 - +150 %
C8.3.5	low flow cutoff	set low values to zero	min-max: 00.0 - 20.0
C8.3.6	time constant	within set time, measurements are averaged, displayed and sent to current output	min-max: 000.1 - 100.0
C8.3.7	format 1.line	number of decimals	automatic, No.x.xxxx (no - four decimals)
C8.3.8	measurement 2.line		bargraph, operating hours, counter 1, counter 2, diagnosis value, SNR, gain, flow speed, mass flow, VoS, volume flow
C8.5.1	select range	set Y-axis scaling	manual, automatic
C8.5.2	range	active if under select range (C5.5.1) manual is selected	min-max: -100 - +100%
C8.5.3	time scale	set X-axis scaling	min-max: 001 - 100 min
C8.6.2	save settings		factory settings, back up 1, back up 2, cancel
C8.6.3	load settings		factory settings, back up 1, back up 2, cancel
C8.6.4	password quick setup		0000 - 9999
C8.6.5	password setup		0000 - 9999
C8.7	units		
C8.7.1	volume flow		L/s, L/min, L/h, m3/s, m3/min, m3/h, m3/d, ft3/s, ft3/min, ft3/h, gal/s, gal/min, gal/h, gal/d, IG/s, IG/min, IG/h, IG/d, bbl/h, bbl/d, free unit
C8.7.2	mass flow		kg/s, kg/min, kg/h, t/min, t/h, t/d, lb/s, lb/min, lb/h, ST/min, ST/h, ST/d, LT/h, LT/d, gs, g/min, g/h, free unit
C8.7.3	flow speed		m/s, ft/s
C8.7.4	velocity		m/s, ft/s
C8.7.5	volume		m3, in3, ft3, yd3, mL, L, hL, gal, IG, bbl, free unit
C8.7.6	mass		mg, g, kg, t, oz, lb, ST, LT, free unit
C8.7.7	density		kg/L, kg/m3, lb/ft3, lb/gal, free unit
C8.7.8	viscosity		cSt, m2/s, mm2/s
C8.8.1	HART	factory setting: HART communication on; generates F: application error open circuit A	







## 7.2 Cleaning

- Keep screw thread of the covers of the UFC 300 F signal converter clean.
- Do not damage the screw thread and the gasket.
- Never allow dirt to accumulate.
- Grease the screw thread with Teflon grease.

## 7.3 Exchange of electronics unit



### CAUTION!

The following instructions shall always be carefully followed and only be performed by trained personnel, familiar with the safety requirements and electronics.

**Before opening the UFC 300 housing:**



### DANGER!

Make sure that all connecting cables are safely disconnected from all external sources.



### NOTE!

Make notes of important specific data, before exchanging the electronics. Menu settings are stored on the circuit board (or backplane), that is fixed to the housing. After exchange of electronics unit and power-up, the following start up screen appears:

**Load all data ?**

| Select yes

**i** - if in the screen appears “**load sensor data**”, the electronics units were not fully compatible. You can proceed by selecting yes. Note that all settings need to be checked and changed. Only the sensor calibration data are loaded.

- if in the screen appears “**load no data**”, all data have been lost. Contact your local KROHNE representative.







**CAUTION!**

Please pay attention that the same amount of force is applied on both pullers, otherwise the connector at the backside can be damaged.




Figure 7-4: Insert new board and finish exchange



**DANGER!**

Electrostatic discharge (ESD) can damage electronic parts. Make sure to discharge yourself by wearing a wrist strap. If no wrist strap is available, ground yourself by touching a metal surface that is grounded.

- | Remove the printed circuit board 6 from the electronics unit 4.
- | Check compatibility between the removed and new electronics unit, by checking the power voltage and by reading the version numbers of all boards 4.
- | Slide the new electronics unit partially back into the housing.
- | Mount the small printed circuit board back onto the sensor driver board.
- | Push back the metal pullers 5 simultaneously with the electronics unit.  
Don't use excessive force, otherwise the connector at the backside can be damaged!
- | Re-install the display and make sure not to kink the display's flat ribbon cable.
- | Screw the electronics unit back to the housing with the two M4 screws.
- | Replace cover and tighten down by hand.
- | Connect power.

7.3.2 UFC 300 W



**DANGER!**

Disconnect power!




Figure 7-5: Unlock and open door

**The following procedures have to be carried out:**

- | Turn locking screw to the left **1** to unlock the lower white door.
- | Open lower white door.
- | Pull metal slider, positioned at the left upper angle, downwards.
- | Open upper blue door **2**.




Figure 7-6: Pull off display

- | Pull off the display 3 by pressing the plastic holders on both sides 4 and carefully lay the display aside.




Figure 7-7: Release printed circuit board

- | Unscrew the two M4 screws 7 at the electronics unit 5.
- | Carefully slide the electronics unit as indicated 4, then lift it out of the housing.



**DANGER!**

Electrostatic discharge (ESD) can damage electronic parts. Make sure to discharge yourself by wearing a wrist strap. If no wrist strap is available, ground yourself by touching a metal surface that is grounded.



## 7.4 Replacing the main fuse



**CAUTION!**

The following instructions shall always be carefully followed and only be performed by trained personnel, familiar with the safety requirements and electronics.

The mains fuse is in accordance with IEC 127-2. The size is diameter 5 x 20 mm / 0.79" length.

**Underneath codings for the mains fuse apply:**

**100...230 VAC power supply:** 0.8 AT/H/250 , breaking capacity 1500 Ampere at 250 V

**24 VAC/DC power supply:** 2 AT/H/250 , breaking capacity 1500 Ampere at 250 V



**DANGER!**

Before opening the UFC 300 housing:  
Make sure that all connecting cables are safely disconnected from all external sources.

### 7.4.1 UFC 300 F



**DANGER!**

Disconnect power!

**The following procedures have to be carried out:**

- | Unscrew the display cover of the electronics compartment by hand, by turning it counter clockwise **1** .
- | Unscrew the screws (M4) to release the electronics unit from the F-housing **2** .
- | Pull the two metal clips at the left and right of the display **2** , using a screwdriver or similar tool.
- | Partially pull out the electronics unit.



7.4.2 UFC 300 W



**DANGER!**

Disconnect power!




Figure 7-10: Unlock and open door

**The following procedures have to be carried out:**

- | Turn locking screw **1** to the left to unlock the lower white door.
- | Open lower white door.
- | Pull metal slider, positioned at the left upper angle, downwards.
- | Open upper blue door **2**.





### 7.5 Spare parts availability

It is the policy of KROHNE to provide operational spare parts for any flowmeter or major accessory for a period of ten (10) years after shipment of the final production run of that flowmeter.

Operational spare parts are defined as those that are susceptible to failure during their normal operation.

### 7.6 Service availability

KROHNE provides a variety of services to support its customers after warranty expiration.

Repair, technical support and training can be provided.



**NOTE!**

For detailed information please contact your local KROHNE representative.

## 7.7 Returning the device to the manufacturer

### 7.7.1 General information

This device has been carefully manufactured and tested. If installed and operated in accordance with these operating instructions, it will rarely present any problems.



**CAUTION!**

Should you nevertheless need to return a device for inspection or repair, please pay strict attention to the following points:

- Due to statutory regulations on environmental protection and safeguarding the health and safety of our personnel, KROHNE may only handle, test and repair returned devices that have been in contact with products without risk to personnel and environment.
- This means that KROHNE can only service this device if it is accompanied by the following certificate (see next section) confirming that the device is safe to handle.



**CAUTION!**

If the device has been operated with toxic, caustic, flammable or water-endangering products, you are kindly requested:

- to check and ensure, if necessary by rinsing or neutralizing, that all cavities are free from such dangerous substances,
- to enclose a certificate with the device confirming that is safe to handle and stating the product used.

7.7.2 Form (for copying) to accompany a returned instrument

Company:		Address:	
Department:		Name:	
Tel. No.:		Fax No.:	
The meter enclosed, type:			
KROHNE Commission or Series No.:			
has been operated with the following liquid:			
Because this liquid is:	<input type="checkbox"/>	hazardous to water	
	<input type="checkbox"/>	toxic	
	<input type="checkbox"/>	caustic	
	<input type="checkbox"/>	flammable	
	<input type="checkbox"/>	We have checked that all cavities in the unit are free from such substances.	
	<input type="checkbox"/>	We have flushed out and neutralized all cavities in the unit.	
We herewith confirm that in returning this unit there is no risk to man or environment through any residual liquid contained in it!			
Date:		Company stamp:	
Signature:			

7.8 Disposal



**CAUTION!**

Disposal must be carried out in accordance with legislation applicable in your country.

## 8.1 Technical data

### Ultrasonic flowmeter OPTISONIC 6300

#### Versions

OPTISONIC 6300	Standard
OPTISONIC 6300 - EX	Option

#### Performance

Measurement functionality	Standard actual volume flowrate and totalised volume
Measuring range	0...20 m/s / 0...66 ft/s
Max. deviation (under reference conditions)	< ± 1% of M.V. for DN≥50 mm / 2", v>0.5 m/s / 1.5 ft/s
	< ± 3% of M.V. for DN<50 mm / 2", v>0.5 m/s / 1.5 ft/s
Repeatability	< ± 0.2%
Process conditions	Solid particle content < 5% (by volume)
	Gas content < 2% (by volume)

#### Measurement configurations

Single path, single pipe	Standard
Dual path, single pipe	Option
Dual pipe, single path	Option

### Ultrasonic flow sensor OPTISONIC 6000

#### Versions

OPTISONIC 6000 - medium (DN50...DN400 / 2"...16")	Standard
OPTISONIC 6000 - small (DN15...DN100 / ½"...4")	Option
OPTISONIC 6000 - large (DN200...DN4000 / 8"...160")	Option
OPTISONIC 6000XT - medium (ext. temp. DN50...DN400 / 2"...16")	Option
OPTISONIC 6000XT - small (ext. temp. DN15...DN100 / 2"...4")	Option

#### Pipe specifications

Material: metal, plastic, ceramic, asbestos cement, internal / external coated pipes (coatings and liners fully bonded to pipewall)	Standard
Maximum pipewall thickness of 75 mm / 2.95" (metal)	Standard

#### Protection class

IP66/67	Standard
---------	----------

#### Electric signal level

Ex-i, intrinsically safe circuits, floating	Standard
---	----------

#### Process temperature

-40...+120°C / -40...+248°F	Standard
-50...+200°C / -58...+392°F, XT version	Option

#### Signal cable length

5 m / 15 ft	Standard
-------------	----------

## 8 TECHNICAL DATA

10 m / 30 ft	Option
20 m / 60 ft	Option
30 m / 90 ft	Option

### Ultrasonic flow converter UFC 300

#### Versions

W (wall)	UFC 300 W
F (field)	UFC 300 F

#### Display languages

With local display	Standard
English, French, German, Dutch	Standard

#### Flow sensor

OPTISONIC 6000	DN 15...4000 / ½"...160"
----------------	--------------------------

#### Communication

Current, pulse & status output, HART® communication, control input	Standard
Modular I/O	Option

#### Power supply

100...230 VAC (-15/+10%), 50/60 Hz	Standard
24 V AC/DC (24 VAC: +10% / -15%, 50/60 Hz; 24 VDC: +30% / -25%)	Option
Power consumption	22 VA

#### Approvals

EEx - zone 1 / 2	Option 1
FM - Class I DIV 1 / 2	Option 1
CSA - GP / Class I DIV 1 / 2	Option 1

#### Protection category

W (wall)	IP 65 (eq. to NEMA 4/4X)
F (remote)	IP 66 / 67 (eq. to NEMA 6)

#### Temperature

Process	see flow sensor
Ambient	-40...+65°C / -40...+149°F
Storage	-50...+70°C / -58...+158°F

#### Cable connection

M20 x 1.5	Standard
½" NPT	Option
PF ½	Option

#### Materials used

Die-cast aluminium with polyurethane coating (F-version)	Standard
Polyamide - polycarbonate (W-version)	Standard
Stainless steel 316 L / 1.4404 (F-version)	Option

1 UFC 300 F only

## I/O Specifications

### Overall functionality

Function	Continuous measurement of actual volume flow, mass flow, flow speed, velocity of sound, gain, SNR, diagnosis value
	Bidirectional flow measurement and totalisation
	Signal quality bar graph

### Current output

Function	All operating data configurable; galvanically isolated; HART® communication
Settings	Q = 0%: 0...15 mA
	Q = 100%: 10...22 mA
	Error identification: 0...22 mA
Connection	
Basic / Modular IO: Active	$I \leq 22 \text{ mA} / R_L \leq 1 \text{ k}\Omega$
Ex-i: Active	$I \leq 22 \text{ mA} / R_L \leq 470 \text{ }\Omega$
	$U_0 = 21 \text{ V} / I_0 = 90 \text{ mA}$
	$P_0 = 0.5 \text{ W}$
	$C_0 = 90 \text{ nF} / L_0 = 2 \text{ mH}$
Basic / Modular IO: Passive	$I \leq 22 \text{ mA} / U \leq 32 \text{ VDC}$
Ex-i: Passive	$I \leq 22 \text{ mA}$
	$U_i = 30 \text{ V} / I_i = 100 \text{ mA}$
	$P_i = 1 \text{ W}$
	$C_i = 10 \text{ nF} / L_i \sim 0 \text{ mH}$


### Pulse output and Status output

Function	Configurable as pulse output, identification for automatic range change, indicator of flow direction, overflow, errors, trip point or empty pipe indication
Settings	Q = 100%: 0.0001... 10000 pulses per second or pulses per unit volume
	Pulse width: 0.05...2000 ms or auto or sym.
	Status: On or Off
Connection	
Basic / Modular IO: Passive	$f \leq 10 \text{ kHz} / I \leq 20 \text{ mA}$
	$f \leq 10 \text{ Hz} / I \leq 100 \text{ mA}$
	$U \leq 32 \text{ VDC} / I \leq 100 \text{ mA}$
Passive	$U_i = 30 \text{ V} / I_i = 100 \text{ mA}$
	$P_i = 1 \text{ W}$
	$C_i = 10 \text{ nF} / L_i \sim 0 \text{ mH}$
Active	$U_{\text{nom}} = 24 \text{ VDC} / I < 1 \text{ mA}$
	$U_0 = 1.5 \text{ V at } 10 \text{ mA}$
Namur (acc. to EN 60947-5-6)	Passive

Control input

Function	Freeze output (e.g. during cleaning), forced return to zero, counter and error reset, ext. range selection.
Settings	Freeze outputs, output zero, reset counter, reset error, start batch (in batch mode)
Connection	
Basic / Modular IO: Active	$I_{nom} = 16 \text{ mA} / U_{nom} = 24 \text{ VDC}$
Basic / Modular IO: Passive	$U \leq 32 \text{ VDC}$
	$U_{on} > 19 \text{ VDC} / U_{off} < 2.5 \text{ VDC}$
Namur (acc. to EN 60947-5-6)	Active

8.2 Dimensions and weights




Version	Dimensions [mm]			Approx. weight (without cable / strip)
	L	H	W	[kg]
small	496.3	71	63.1	2.7
medium	826.3	71	63.1	3.6
large	496.3 <sup>1</sup>	71 <sup>1</sup>	63.1 <sup>1</sup>	2.7 <sup>1</sup>

<sup>1</sup> value for one of the 2 delivered rails

Version	Dimensions [inches]			Approx. weight (without cable / strip)
	L	H	W	[lbs]
small	19.5	2.8	2.5	6.0
medium	32.5	2.8	2.5	7.9
large	19.5 <sup>1</sup>	2.8 <sup>1</sup>	2.5 <sup>1</sup>	6.0 <sup>1</sup>

<sup>1</sup> value for one of the 2 delivered rails

# 8 TECHNICAL DATA




- 1 UFC 300 W
- 2 UFC 300 F

Version	Dimensions [mm]						Weight [kg]
	a	b	c	f	g	h	
UFC 300 W	198	138	299	-	-	-	2.4
UFC 300 F	202	120	155	141	296	277	5.7

Version	Dimensions [inches]						Weight [lbs]
	a	b	c	f	g	h	
UFC 300 W	7.8	5.4	11.8	-	-	-	5.3
UFC 300 F	7.75	4.75	6.1	5.5	11.6	10.9	12.6



# 8 TECHNICAL DATA



Dimensions and weights in mm and kg

	Dimensions [mm]			Approx weight without cable/metal [kg]
	a	b	c	
Cable box	102	197	67	0.85

Dimensions and weights in inches and lbs

	Dimensions [inches]			Approx weight without cable/metal [lbs]
	a	b	c	
Cable box	4.01	7.76	2.64	1.87

## KROHNE Product Overview

- Electromagnetic flowmeters
- Variable area flowmeters
- Mass flowmeters
- Ultrasonic flowmeters
- Vortex flowmeters
- Flow controllers
- Level measuring instruments
- Pressure gauges
- Temperature measuring instruments
- Water solutions & analysis
- Oil and gas turnkey solutions

## Addresses:

### Germany

#### Northern sales office

KROHNE Messtechnik GmbH & Co. KG  
Bremer Str. 133  
D-21073 Hamburg  
Phone: +49 (0)40 767 3340  
Fax: +49 (0)40 767 33412  
nord@krohne.de  
ZIP code: 10000 - 29999, 49000 - 49999

#### Western and middle sales office

KROHNE Messtechnik GmbH & Co. KG  
Ludwig-Krohne-Straße  
D-47058 Duisburg  
Phone: +49 (0)203 301 416  
Fax: +49 (0)203 301 10416  
west@krohne.de  
ZIP code: 30000 - 34999, 37000 - 48000, 50000 - 53999, 57000 - 59999, 98000 - 99999

#### Southern sales office

KROHNE Messtechnik GmbH & Co. KG  
Landsberger Str. 392  
D-81241 Munich  
Phone: +49 (0)89 121 5620  
Fax: +49 (0)89 129 6190  
sued@krohne.de  
ZIP code: 0 - 9999, 80000 - 89999, 90000 - 97999

#### Southwestern sales office

KROHNE Messtechnik GmbH & Co. KG  
Rüdesheimer Str. 40  
D-65239 Hochheim/Main  
Phone: +49(0)6146) 827 30  
Fax: +49 (0)6146 827 312  
rhein-main@krohne.de  
ZIP code: 35000 - 36999, 54000 - 56999, 60000 - 79999

#### Instrumentation and control equipment catalog

TABLAR Messtechnik GmbH  
Ludwig-Krohne-Straße 5  
D-47058 Duisburg  
Phone: +49 (0)2 03 305 880  
Fax: +49 (0)2 03 305 8888  
kontakt@tablar.de www.tablar.de

### KROHNE sales companies

#### International

##### Australia

KROHNE Australia Pty Ltd  
Quantum Business Park 10/287  
Victoria Rd Rydalmere NSW 2116  
Phone: +61 2 8846 1700  
Fax: +61 2 8846 1755  
krohne@krohne.com.au

##### Austria

KROHNE Austria Ges.m.b.H.  
Modedcenterstraße 14  
A-1030 Vienna  
Phone: +43 (0)11/203 45 32  
Fax: +43 (0)1/203 47 78  
info@krohne.at

##### Belgium

KROHNE Belgium N.V.  
Brusselstraat 320  
B-1702 Groot Bijgaarden  
Phone: +32 (0)2 4 66 00 10  
Fax: +32 (0)2 4 66 08 00  
krohne@krohne.be

##### Brazil

KROHNE Conaut Controles  
Automaticos Ltda.  
Estrada Das Águas Espraiadas, 230  
C.P. 56 06835 - 080 EMBU - SP  
Phone: +55 (0)11-4785-2700  
Fax: +55 (0)11 4785-2768  
conaut@conaut.com.br

##### China

KROHNE Measurement Instruments  
(Shanghai) Co. Ltd., (KMIC)  
Room 1501  
1033 Zhaojiabang Road  
Shanghai 200030  
Phone: +86 21 6487 9611  
Fax: +86 21 6438 7110  
info@krohne-asia.com

##### Czech Republic

Soběsická 156  
63800 Brno  
Phone: +420 (0)545.242 627  
Fax: +420 (0)545 220 093  
brno@krohne.cz

##### France

KROHNE S.A.S.  
Les Ors BP 98  
F-26103 ROMANS Cedex  
Phone: +33 (0)4 75 05 44 00  
Fax: +33 (0)4 75 05 00 48  
info@krohne.fr

##### Great Britain

KROHNE Ltd.  
Rutherford Drive  
Park Farm Industrial Estate  
Wellingborough  
Northants NN8 6AE  
Phone: +44 (0)19 33 408 500  
Fax: +44 (0)19 33 408 501  
info@krohne.co.uk

##### CIS

Kanex KROHNE Engineering AG  
Business-Centre Planeta  
Office 404 ul.  
Marxistskaja 3  
109147 Moscow/Russia  
Phone: +7 (0)095 911 7165  
Fax: +7 (0)095 742 8873  
krohne@dol.ru

##### India

Krohne Marshall Ltd.  
A-34/35, M.I.D.C. Industrial Area,  
H-Block  
Pimpri Poona 411018  
Phone: +91 (0)202 744 2020  
Fax: +91 (0)202 744 2020  
pcu@vsnl.net

##### Iran

KROHNE Liaison Office  
North Sohrevardi Ave. 26,  
Sarmad St. Apt. #9  
Tehran 15539  
Phone: +9821 8874 5973  
Fax: +9821 8850 1268  
krohne@krohneiran.com

##### Italy

KROHNE Italia Srl.  
Via V. Monti 75  
I-20145 Milan  
Phone: +39 02 4300 6661  
Fax: +39 02 4300 6666  
info@krohne.it

##### Korea

KROHNE Korea  
Room 508 Miwon Bldg 43  
Yoido-Dong Youngdeungpo-Ku  
Seoul, Korea  
Phone: 00-82-2-782-1900  
Fax: 00-82-2-780-1749  
krohnekorea@krohnekorea.com

##### Netherlands

KROHNE Nederland B.V.  
Kerkeplaat 14  
NL-3313 LC Dordrecht  
Phone: +31 (0)78 630 6200  
Fax: +31 (0)78 630 6405  
Service Direct: +31 (0)78 630 6222  
info@krohne.nl

##### Norway

KROHNE Norway A.S.  
Ekholtveien 114  
NO-1521 Moss  
Phone: +47 (0)69 264 860  
Fax: +47 (0)69 267 333  
postmaster@krohne.no

##### Poland

KROHNE Endra Sp.z.o.o.  
ul. Stary Rynek Oliwskiego 8a  
80-324 Gdansk  
Phone: +48 (0)58 520 9211  
Fax: +48 (0)58 520 9212  
wendraszka@krohne.pl

##### Switzerland

KROHNE AG  
Uferstr. 90  
CH-4019 Basel  
Phone: +41 (0)61 638 30 30  
Fax: +41 (0)61 638 30 40  
info@krohne.ch

##### Singapore

Tokyo Keiso - KROHNE (Singapore)  
Pte. Ltd.  
14, International Business Park,  
Jurong East  
Chiyoda Building, #01-01/02  
Singapore 609922  
Phone: (65) 6567 4548  
Fax: (65) 6567 9874  
tks@tokyokeiso-krohne.com.sg

##### Republic of South Africa

KROHNE Pty. Ltd.  
163 New Road  
Halfway House Ext 13  
Midrand  
Phone: +27 (0)11 315 2685  
Fax: +27 (0)11 805 0531  
midrand@krohne.co.za

##### Spain

I.I. KROHNE IBERIA, S.r.l.  
Poligono Industrial Nilo  
Calle Brasil, nº. 5  
28806 Alcalá de Henares Madrid  
Phone: +34 (0)91 883 2152  
Fax: +34 (0)91 883 4854  
krohne@krohne.es

##### USA

KROHNE, Inc.  
7 Dearborn Road  
Peabody, MA 01960  
Phone: +1 (800) FLOWING  
Phone: +1 (978) 535 6060 (in MA)  
info@krohne.com

### Representatives

Argentina  
Cameroon  
Canada  
Chile  
Columbia  
Croatia  
Denmark  
Ecuador  
Egypt  
Finland  
Gabon  
Ghana  
Greece  
Hong Kong  
Hungary  
Indonesia  
Iran  
Ireland  
Israel  
Ivory Coast  
Japan  
Jordan  
Kuwait  
Libya  
Lithuania  
Malaysia  
Mauritius  
Mexico  
Morocco  
New Zealand  
Peru  
Portugal  
Romania  
Saudi Arabia  
Senegal  
Slovakia  
Slovenia  
Sweden  
Taiwan  
Thailand  
Tunisia  
Turkey  
Venezuela  
Yugoslavia

### Other countries

KROHNE Messtechnik GmbH & Co. KG  
Ludwig-Krohne-Str. 5  
D-47058 Duisburg  
Phone: +49 (0)203 301 0  
Fax: +49 (0)203 301 389  
export@krohne.de